



GENERAL NOTES:

1. AN APPROVED BACKFLOW PREVENTION ASSEMBLY SHALL BE INSTALLED BETWEEN THE EXISTING AND NEW WATER MAIN LINES DURING DISINFECTION AND FLUSHING OF THE NEW WATER MAIN.
2. THE NEW WATER MAIN SHALL BE CONNECTED TO THE EXISTING SYSTEM ONLY AFTER THE NEW WATER MAIN IS FLUSHED AND DISINFECTED AND PROPER RESIDUAL READING AND SATISFACTORY BACTERIOLOGICAL SAMPLE RESULTS ARE OBTAINED.
3. THE INTERIORS OF ALL PIPES AND FITTINGS TO BE USED IN FINAL CONNECTION MUST BE SWABBED OR SPRAYED WITH A 1% CHLORINE SOLUTION.

CITY OF TUMWATER, WASHINGTON DEPT. OF PUBLIC WORKS				
METHODS FOR FILLING NEW WATER MAINS				
APPROVED BY:				DWG. NO.
CITY ENGINEER				WA-9.1
DES. PW	DWG. BY PW	CK'D BY KMC	DATE JUNE 2014	NOT TO SCALE