



VALVE BOX DETAIL

GENERAL NOTES:

1. METER BOXES SHOULD NOT BE DESIGNED IN DRIVEWAYS, DRIVEWAY APPROACHES, SIDEWALKS OR CONFLICTED AREAS. WHEN POSSIBLE CREATE PLANTER AREAS FOR METER BOX INSTALLATION.
2. DO NOT INSTALL IN AREAS SUBJECT TO FLOODING.
3. IF REDUCED PRESSURE DEVICE IS USED, RPBA BOX MUST BE FREE DRAINING.

CITY OF TUMWATER, WASHINGTON DEPT. OF PUBLIC WORKS				
IRRIGATION SERVICE FOR COMMERICAL SITES				
APPROVED BY:				DWG. NO.
CITY ENGINEER				WA-25
DES. PW	DWG. BY PW	CK'D BY KMC	DATE JULY 2014	NOT TO SCALE