

## **GENERAL NOTES:**

- THOROUGHLY FLUSH THE LINES PRIOR TO INSTALLING DCVA.
- 2. IF THE IRRIGATION SYSTEM IS TAPPED OFF OF THE DOMESTIC SERVICE LINE, A HEAVY DUTY HAND BALL VALVE MUST BE INSTALLED IN A OFFSET VALVE BOX (CARSON MODEL 910) WITHIN 18" BEFORE THE CHECK VALVE ASSEMBLY. SEE CITY DETAIL.
- 3. THE DEPTH OF THE VAULT SHALL NOT EXCEED 3.5'.

## MATERIAL LIST:

- 1 SERVICE LINE
- 2 UNION
- ③ NIPPLE
- (4) SHUT-OFF VALVE
- (5) CHECK VALVES (D.O.H. APPROVED)
- E) TEST COCKS

CITY OF TUMWATER, WASHINGTON DEPT. OF PUBLIC WORKS

## DOUBLE CHECK VALVE ASSEMBLY FOR 2" OR SMALLER IRRIGATION

APPROVED BY:				DWG. NO.
				WA-35
CITY ENGINEER				
DES.	DWG. BY	CK'D BY	DATE	NOT TO
PW	PW	KMC	JULY 2014	SCALE