



GENERAL NOTES:

1. AN APPROVED BACKFLOW PREVENTION ASSEMBLY SHALL BE INSTALLED BETWEEN THE EXISTING AND NEW WATER MAINS DURING DISINFECTION AND FLUSHING OF THE NEW WATER MAIN.
2. THE NEW WATER MAIN SHALL BE CONNECTED TO THE EXISTING SYSTEM ONLY AFTER THE NEW WATER MAIN IS FLUSHED AND DISINFECTED AND PROPER RESIDUAL READING AND SATISFACTORY BACTERIOLOGICAL SAMPLE RESULTS ARE OBTAINED.
3. THE INTERIORS OF ALL PIPES AND FITTINGS TO BE USED IN FINAL CONNECTION MUST BE SWABBED OR SPRAYED WITH A 1% CHLORINE SOLUTION.

CITY OF TUMWATER, WASHINGTON
DEPT. OF PUBLIC WORKS

**METHODS FOR FILLING
NEW WATER MAINS**

APPROVED BY:

DWG. NO.

CITY ENGINEER

WA-9

DES.
PW

DWG. BY
PW

CK'D BY
KMC

DATE
JULY 2014

NOT TO
SCALE