



GENERAL NOTES:

1. USE CORPORATION STOP CONNECTION. SEE CITY DETAIL.
2. FOR 5/8" X 3/4" DOMESTIC METER SETTERS, MANIFOLD SIZE SHALL BE 3/4" FROM BUSHING AT THE TEE. FOR 1" DOMESTIC METER SETTERS, MANIFOLD SIZE SHALL BE 1" FROM BUSHING AT TEE.
3. FOR 1" FIRE METER SETTER, BRASS PIPE SHALL BE 12' LONG. FOR 1 1/2" FIRE METER SETTER, BRASS PIPE SHALL BE 6" LONG.
4. FIRE METER SETTERS FOR VACANT LOTS SHALL BE INSTALLED AS 1 1/2" METER SETTERS. IF FIRE SPRINKLER DESIGNS HAVE BEEN APPROVED UTILIZING SMALLER SETTERS, THE SETTER SIZE MAY BE REDUCED. USE APPROPRIATE SIZED BUSHING AND BRASS PIPE FROM TEE.
5. THE METER BOXES SHALL BE CENTERED OVER THE METER SETTER ASSEMBLIES AS SHOWN.
6. FOR SINGLE LOT MANIFOLD, ROTATE 2" TEE AT FIRE METER SETTER AND CONNECT WATER SUPPLY TO THIS TEE. USE CORPORATION STOP CONNECTION SEE CITY STANDARD DETAIL.
7. AN APPROVED BACKFLOW PREVENTER IS REQUIRED ADJACENT TO THE DOMESTIC/FIRE METER BOX OR DOWNSTREAM IN THE BUILDING.

CITY OF TUMWATER, WASHINGTON DEPT. OF PUBLIC WORKS				
DOMESTIC AND FIRE SPRINKLER MANIFOLD				
APPROVED BY:				DWG. NO.
CITY ENGINEER				WA-28
DES. PW	DWG. BY PW	CK'D BY KMC	DATE JULY 2014	NOT TO SCALE